NOCOM FLOOR / ROOF DECKING PRE-INSTALLATION CHECKLIST

1. MATERIAL RECEIPT, STORAGE & HANDLING

- ☐ Inspect shipment for damage upon receipt
- ☐ Confirm correct thickness panels are received
- ☐ Report all issues to supplier in 24 hours
- ☐ Store pallets on level solid ground max 3 high
- ☐ Protect from rain and snow (do not use salt / chemicals for de-icing purposes)
- ☐ Store above 0 degrees, allow proper acclimation of 3 days on site
- ☐ Transport, handle and store materials carefully

2. SITE SAFETY & BEST PRACTICES REVIEW

- ☐ Review install specs with installers
- ☐ Review loading limitations with all laborers
- ☐ Review areas of traffic / abuse and plan protection boards

3. FRAMING SYSTEM REVIEW

- ☐ Framing meets requirements of application
- ☐ Framing spaced max 24" OC (for ¾" thick floors)
- ☐ Framing is properly blocked / braced
- ☐ No protruding fasteners on top flange of framing
- ☐ Framing is level, in plane and free from twists & bows

4. PANEL INSTALLATION

- ☐ Inspect each board, do not install damaged boards
- ☐ Handle panels gently
- ☐ Confirm correct panel layout and staggering
- ☐ Confirm correct adhesive used as needed
- ☐ Confirm correct fasteners and fastener placement
- ☐ Start fasteners at one corner and fan out
- ☐ All edges of panel supported by framing or T&G
- ☐ Proper support at cut-outs and penetrations

5. FINISHES

- ☐ Proper floor prep & system conditioning prior to finishing
- ☐ Carefully review specs for finishes

IMPORTANT: This checklist is offered for general information purposes only. All applications to be reviewed and approved by licensed design professionals as meeting requirements of application & building code. Assemblies must be built as-tested and per published designs to achieve published performance. Please refer to complete tested assemblies for requirements. Failure to follow current installation instructions may affect product performance & warranty.